Access with card - BNA F

To be read, RFID cards must be placed in the area below the printer on the **control console (7).**

Correct reading of the cards will be confirmed by a "**BEEP**" sound.

Each card has a 6-digit serial number and a dedicated function:

DEPOSIT Card for depositing.

SUPERVISOR Card for advanced functions and printing.

WITHDRAWAL Card reserved for the transport of valuables.


DEPOSITO
DEPOSIT
Serial Number
Matricola
123456
italdes


SUPERVISORE
SUPERVISOR
Serial Number
Matricola
123456
italdes


PRELIEVO
WITHDRAWAL
Serial Number
Matricola
123456
italdes