Banknote acceptor - BNA F

You can identify these parts on the bill acceptor:

- **Banknote tray** Place the bills to initiate a deposit **placing them correctly**.
- **Reject Slot** Unrecognized banknotes are rejected here.
- **Upper / Lower Slot** Spaces where you can possible access to remove anystuck banknotes or foreign bodies.






Upper Slot
BNA
italbes
IMPOSSIBILE EFFETTUARE
ULTERIORI VERSAMENTI
Reinizializza



Opening the Upper Compartment


To open the upper compartment, press the **green lever A** located behind the note tray and lift the compartment from the rear. **To close the upper compartment, lower it until you hear a clicking sound.**


A
BNA
italbes


BNA
italbes


Opening the Lower Compartment

To open the lower compartment, lift the **green lever B** and lift the compartment upwards. **To close the lower compartment, lower it until you hear a clicking sound.**



Opening the Reject Slot

To open the Reject Slot, first open the lower compartment, then press the **green lever C** and the base will lower itself. To close the Reject Slot, lift the base until it clicks into place. you will not hear a snapping noise or close the bottom compartment as described above.




Removing stuck banknotes

By following the instructions for opening the slots, you can remove banknotes stuck inside the acceptor.Shown here are examples of banknotes stuck inside the acceptor, found after opening the corresponding slot.
Once you've removed the banknotes and closed all the compartments, you'll need to tap the following button on the monitor:



(click the button above for specifications)

Banknote stopped in the upper compartment:



Banknote stopped in the lower compartment:



Banknote stuck in the Reject Slot:

