
Introduction - Login - BNA F

To be able to use the BNA F safe è necessary to identify yourself via an **RFID CARD** and/or a **CODE.**

The home screen è indication of the type of access enabled:

Access via RFID tag



Access via RFID Card or Code


SERIAL NO.
12345677
NOTIFICATIONS
VIDEO
TUTORIAL
PLACE THE CARD
PLACE THE CARD
ON THE RFID READER
DEPOSIT
ACCESS WITH CODE
PRESS NEXT TO CONTINUE
NEXT