

Supervisor

Supervisor

Supervisor Access

To access the **Supervisor Menu**, place the **Supervisor card** on the **RFID card reader** of the Console.



Supervisor PIN

Once the Supervisor card has been scanned, you will be asked for the PIN code associated with the Supervisor card you are using. If the Supervisor card PIN is the standard "1234," you will be asked if you want to change it. If you don't remember your PIN code, contact support.



SERIAL NO.
12345672

NOTIFICATIONS
▼

VIDEO
TUTORIAL

ENTER THE PIN CODE:

USER PIN

1

2

3

4

5

6

7

8

9

.


0



BACK



CHANGE PIN



Menu Supervisor

Within the Supervisor Menu, you will find the following functions: **Prints** - Allows you to reprint receipts or transaction summary receipts: **Connection Test** - Checks the connectivity of the machine. BNA SMALL safe network settings.

System Info - Function to be used upon request for support.

Update Configuration - Function to be used upon request for support.

Company Card Management - Register/Delete deposit cards.

Reboot - Reboots the BNA SMALL safe system.

Set Date and Time - Sets the date and time for the BNA SMALL safe.

Modem Setup - Use this function when requesting support.

Audio Guide - Enable/Disable the audio guide during deposits.

Back- Exit the Supervisor Menu.

SUPERVISOR



PRINTS



CONNECTION TEST



SYSTEM INFO



UPDATE
CONFIGURATION



CUSTOMER'S CARDS
MANAGEMENT



RESTART



SET DATE AND TIME



MODEM SETTINGS



DISABLE VOICE
GUIDANCE



BACK

Supervisor Prints

Within the Supervisor Menu, you will find the following functions:

LAST DEPOSIT: Print a copy of the receipt for your last deposit.

LIST OF LATEST TRANSACTIONS: Print a copy of the receipt for a single Deposit or Withdrawal, choosing from the transactions of the last 3 days.

TODAY'S TOTAL: Prints the total Deposited for the current day, up to that point.


TODAY'S TRANSACTIONS: Prints the list of Deposit and Withdrawal transactions for the current day, up to that point.

YESTERDAY'S TOTAL: Prints the total Deposited for the current day, up to that point. yesterday.

YESTERDAY'S TRANSACTIONS: Prints the list of Deposit and Withdrawal transactions for yesterday.

TOTAL FOR THE LAST 30 DAYS: Prints the total Deposits for each day, for the last 30 days, starting from yesterday.

Back - Return to [Supervisor Menu](#).





YESTERDAY'S TOTAL



YESTERDAY'S
TRANSACTIONS



LAST 30 DAYS TOTAL



BACK