

Menu Supervisor - BNA SMALL

Within the Supervisor Menu, you will find the following functions: **Prints** - Allows you to reprint receipts or transaction summary receipts. **Connection Test** - Checks the connectivity of the machine. BNA SMALL safe network settings.

System Info - Function to be used upon request for support.

Update Configuration - Function to be used upon request for support.

Company Card Management - Register/Delete deposit cards.

Reboot - Reboots the BNA SMALL safe system.

Set Date and Time - Sets the date and time for the BNA SMALL safe.

Modem Setup - Use this function when requesting support.

Audio Guide - Enable/Disable the audio guide during deposits.

Back - Exit the Supervisor Menu.

SUPERVISOR



PRINTS



CONNECTION TEST



SYSTEM INFO



UPDATE
CONFIGURATION



CUSTOMER'S CARDS
MANAGEMENT



RESTART



SET DATE AND TIME



MODEM SETTINGS



DISABLE VOICE
GUIDANCE



BACK

VOICE GUIDEAt the beginning of each Deposit operation, you can choose whether or not to have voice guidance. Or you can permanently disable it from the Supervisor menu.

25/11/24
12:25:01

NOTIFICATIONS
▼

VIDEO
TUTORIAL

WHAT TO DEPOSIT?

USER: 0000004852

CUSTOMER: TALDES S.R.L.

DO YOU WANT THE VOICE
GUIDANCE?

DEPOSIT TOTAL € 0,00 ?

PERMANENT ON/OFF BY SUPERVISOR

SAFE BAG pcs 0

< NO YES >

COMPLETE THE DEPOSIT