

Introduction - Login - BNA SMALL

To be able to use the BNA FX safe è necessary to identify yourself via an RFID CARD and/or a CODE.

The home screen è indication of the type of access enabled:

Access via RFID tag




SERIAL NO.
12345671

NOTIFICATIONS
▼

VIDEO
TUTORIAL

PLACE THE CARD

PLACE THE CARD
ON THE RFID READER



Access via RFID Card or Code




SERIAL NO.
12345677

NOTIFICATIONS
▼

VIDEO
TUTORIAL

PLACE THE CARD

PLACE THE CARD
ON THE RFID READER



DEPOSIT
ACCESS WITH CODE

PRESS NEXT TO CONTINUE



NEXT