

Access with code - BNA SMALL

06/05/2026 3:46 pm CEST

After tapping the Next button on the home screen:

Enter your user code and tap the NEXT button.

Depending on your cash register configuration, this will be the default. You can then **start depositing**. Otherwise, additional personalized customer data may be requested, such as slip code, receipt code, cashier number, etc.

SERIAL NO. 12345677

NOTIFICATIONS

VIDEO TUTORIAL

ENTER THE USER CODE:

PRESS NEXT TO CONFIRM

1111

1 2 3 4 5 6 7 8 9 0

Q W E R T Y U I O P

A S D F G H J K L -

← Z X C V B N M →

BACK NEXT

If enabled by the cash register configuration, the PIN associated with the previously entered user code will also be requested.

If you know the PIN associated with the user code, you can change it by tapping the "Change PIN" button.

SERIAL NO. 12345672

NOTIFICATIONS

VIDEO TUTORIAL

ENTER THE PIN CODE:

USER PIN

1111

1 2 3

4 5 6

7 8 9

. 0 →

BACK CHANGE PIN

