

Banknote acceptor - BNA SMALL


06/05/2026 3:40 pm CEST

Check the front panel

Remove the tray, pressing it as if it were a clothespin.



Do not press on the transparent part.



Using a small screwdriver, push the yellow lever in and remove the cartridge.



If you find a banknote you have solved the problem.



Removing the head

Forcefully press the **yellow button (2)**.



With your other hand, grasp the acceptor and pull it down, making a twist.





Lean on a table and open it.



Recover the banknotes.

