

Deposit Account


Introduction

Once you have logged in, [Login](#) will take you to the deposit session. Where you can choose what to deposit:

- “**BANKNOTES**” To deposit using the Acceptor
- “**SAFE BAG**” to deposit valuables using Safebags (sealed envelopes)

The value of **Banknotes** deposited using the Acceptor is credited upon completion of the deposit. Valuables deposited using **Safebags** are credited after verification in the counting room.

Tap **COMPLETE DEPOSIT** to end the deposit session.



Positioning of banknotes

How to place the banknotes

Insert bundles of 30/35 banknotes.



Align the bills on the right.



Do not touch the yellow button while depositing.




Do not insert additional banknotes during deposit.




Banknote deposit

Start Deposit

Before starting your deposit, please follow the [instructions for Banknote Placement](#). After placing the banknotes on the acceptor tray, tap the **BANKNOTES** button on the monitor.




If the acceptor detects the presence of banknotes on the tray, it will automatically begin counting them; otherwise, the screen will display "INSERT BANKNOTES." and after placing them on the tray, you will have to press the "NEXT" button.




Deposit in progress

For each deposit of banknotes inside the safe, the successful operation is confirmed on the monitor.




Deposit Finished

The total amount released into the vault during a deposit session will be referred to as the "DEPOSIT TOTAL."



Once you've completed a deposit, you can continue depositing by tapping the **BILLS** button again.



Deposit Details

Once you have deposited securities, you can tap the **question mark [?]** to check the number of banknotes deposited, broken down by denomination.



SERIAL NO.
10015063

NOTIFICATIONS
▼

VIDEO
TUTORIAL

WHAT TO DEPOSIT?

USER: 0000004852

CUSTOMER: ITALDES S.R.L.



BANKNOTES



SAFE BAG

DEPOSIT TOTAL


EUR 3130.00



SAFE BAG

pcs 0

COMPLETE THE DEPOSIT



Completing Deposit

When you have finished depositing your assets, tap "COMPLETE DEPOSIT."



SERIAL NO.
10015063

NOTIFICATIONS
▼

VIDEO
TUTORIAL

WHAT TO DEPOSIT?

USER: 0000004852

CUSTOMER: ITALDES S.R.L.



BANKNOTES



SAFE BAG

DEPOSIT TOTAL

EUR 3130.00


?

SAFE BAG

pcs 0

COMPLETE THE DEPOSIT


Upon completing the deposit, a receipt for the deposited banknotes and registered Safebags will be printed.



Safebag deposit

Selecting SAFEBAG DEPOSIT indicates the type of value placed in the safebag that, ONCE registration is complete, you will insert into the BNA SMALL safe through the appropriate slot [\(3\)](#).

- BANKNOTES Banknotes that the acceptor rejects because they are very dirty, worn, damaged, or foreign currency (depends on the type of configuration.)
- COINS Note: The BNA F3 safe is not Designed to accommodate hundreds/thousands of coins.
- CHECKS



Registration

To register the safebag code you can use the Barcode Scanner positioned under the console or enter it manually with the alphanumeric keyboard on the monitor.

To proceed, press NEXT.



SERIAL NO.
12345671

NOTIFICATIONS
▼

VIDEO
TUTORIAL

SCAN THE SAFE BAG CODE

OR ENTER IT MANUALLY

1234567890

QWERTYUIOP

ASDFGHJKL-

⌵ZXCVBNM⌵

<

>

BACKNEXT

Banknotes

Select the currency of the banknotes you insert into the safebag.

To proceed, press NEXT.



Quantity Banknotes

Increment with “ + ” or decrease with “ - ” the number of banknotes per denomination, which you insert into the safebag.



25/11/24
15:32:34

NOTIFICATIONS
▼

VIDEO
TUTORIAL

ENTER THE AMOUNT OF THE
SAFE BAG

SAFE BAG TOTAL

0

5.00	X	0	=	0.00		
10.00	X	0	=	0.00		
20.00	X	0	=	0.00		
50.00	X	0	=	0.00		
100.00	X	0	=	0.00		
200.00	X	0	=	0.00		
500.00	X	0	=	0.00		





BACK

NEXT

Check

Enter the check number you're placing in the safebag.

If the check number has a barcode, you can use the barcode reader located under the console.

To proceed, press NEXT.



SERIAL NO.
12345671

NOTIFICATIONS
▼

VIDEO
TUTORIAL

ENTER THE CHECK NUMBER

12134567890

1	2	3	4	5	6	7	8	9	0
Q	W	E	R	T	Y	U	I	O	P
A	S	D	F	G	H	J	K	L	-
↵	Z	X	C	V	B	N	M	⌫	

<

>

BACKNEXT

Check Amount

Type the amount of the check you place in the safebag.

To proceed, press NEXT.



SERIAL NO.
12345671

NOTIFICATIONS
▼

VIDEO
TUTORIAL

ENTER THE CHECK AMOUNT

MAX AMOUNT €
25,000.00

1250

1	2	3
4	5	6
7	8	9
,	0	⬅️✕

⬅️

➡️

BACKNEXT

Finish Deposit

The final registration screen summarizes the declared amount you deposited into the safe using the safebag.

Press BACK to change the registration or the safebag amount.

To finish and print the receipt, press NEXT.

