

Access with code - BNA F3

06/05/2026 2:37 pm CEST

After tapping the Next button on the home screen:

Enter your user code and tap the NEXT button.

Depending on your cash register configuration, this will be the default. You can then **start depositing**. Otherwise, additional personalized customer data may be requested, such as slip code, receipt code, cashier number, etc.

SERIAL NO. 12345677

NOTIFICATIONS

VIDEO TUTORIAL

ENTER THE USER CODE:

PRESS NEXT TO CONFIRM

1111

1 2 3 4 5 6 7 8 9 0

Q W E R T Y U I O P


A S D F G H J K L -

⌵ Z X C V B N M ✕

BACK NEXT

If enabled by the cash register configuration, the PIN associated with the previously entered user code will also be requested.

If you know the PIN associated with the user code, you can change it by tapping the "Change PIN" button.



The screenshot shows a mobile application interface with a dark theme. At the top, there is a header bar with three sections: on the left, a menu icon and 'SERIAL NO. 12345672'; in the center, 'NOTIFICATIONS' with a downward arrow; and on the right, 'VIDEO TUTORIAL'. Below the header, the main content area has the text 'ENTER THE PIN CODE:' in large white letters, followed by 'USER PIN' in smaller white letters. A white rectangular input field is positioned below the text. Underneath the input field is a numeric keypad with digits 1 through 9, 0, and a backspace icon (a grey square with a white 'X'). At the bottom of the screen, there are two buttons: on the left, a circular button with a white left-pointing arrow labeled 'BACK'; on the right, a circular button with a white padlock icon and a circular arrow, labeled 'CHANGE PIN'.