Access with code - BNA F

After tapping the Next button on the home screen:

Enter your user code and tap the NEXT button. Depending on your cash register configuration, this will be the default. You can then **start depositing**. Otherwise, additional personalized customer data may be requested, such as slip code, receipt code, cashier number, etc.



If enabled by the cash register configuration, the PIN associated with the previously entered user code will also be requested. If you know the PIN associated with the user code, you can change it by tapping the "Change PIN" button.

